

S-3602F/P/J/C/M/E/B/V/I Charger/Adaptor

# **USER MANUAL**

**SWIT Electronics Co., Ltd.** 

Tel:+86-25-85805753 Fax:+86-25-85805296 http://www.swit.cc E-mail: contact@swit.cc

### **Characteristics**

- 2-channel simultaneous charging;
- 4-level LED charging indicators;
- ◆ 2-channel simultaneous adapting output

#### Caution

- 1. Only work in the temperature between 0°C-40°C.
- Keep the terminals clean and ensure the reliable connection.
- 3. Do not cover the cooling vent.
- 4. Never try to open the product.
- 5. Do not touch water or use it in wet environment.
- 6. Do not use metal or other conductors to touch the inside of the charger.

### **Compatible Batteries**

**S-3602F:** SWIT S-8972/8970/8770, SONY NP-F970/770 **S-3602M:** SWIT S-8M91/8M71, SONY NP-QM91/71 **S-3602P:** SWIT S-8D62/8D54/8D28, Panasonic CGA-D54S


**S-3602B**: SWIT S-8BG6, Panasonic VW-VBG6 **S-3602J**: SWIT S-8428, JVC BN-V428U **S-3602V**: SWIT S-8823, JVC BN-VF823

S-3602C: SWIT S-8945/8845, Canon BP-945/970G

S-3602I: SWIT S-8I50, JVC SSL-JVC50


#### Charging

- Connect with power lead, the charger is automatically switched on.
- 2. Mount the compatible batteries onto the charging slot, and the LED charging indicator will start to flash and indicates the current capacity of each battery. (25%, 50%, 75% and 100%)
- 3. When the battery is fully charged, all the 4 LEDs will light on and stop flashing.



# **Adapting output**

- 1. There are two 5.5mm pole DC output sockets: Primary output and Secondary output.
- 2. Connect the adaptor power lead into DC socket, and the Adaptor indicator will lights on.
- 3. The two channels output simultaneously and offers totally 3.5A current.
- 4. If only use one channel DC output, please connect to Primary output socket.



## **Specifications**

Power input	100~240VAC, 50/60Hz
Charging output	DC 7V-8.4V, 1.8A×2
Adapting output	DC 8.4V, 3.5A in total
Power consumption	Max 50W
Dimension	136×110×47mm
Mass	360g